



# GRONOMICS® RUSTIC SERIES “TOOL FREE ASSEMBLY”

## Rustic Multi Kit Gardens

Model #

MRGB 48-95-13

MRGB 48-95-26

MRGB L 12-12

MRGB U 16-16

### STEP I

- A) Unpack all of the parts and organize them in ‘like’ stacks. Please read the instructions in its entirety before beginning assembly.
- B) EACH KIT WILL CONTAIN THE FOLLOWING:

### You should have:

QUANTITY	PART DESCRIPTION	PART #
4	4” x 4” x 13” Corner Post	R1300
Parts for the Sides		
8	45” x 5½” x 1” Side Rail (One w/logo)	R4501,R4501L
Packaged & Inspected by: _____ Date _____		

**NOTE:** If you need assistance with parts or have assembly questions, please contact Customer Service either via email at [info@gronomics.com](mailto:info@gronomics.com) or phone at 763-753-7374.



# GRONOMICS® RUSTIC SERIES “TOOL FREE ASSEMBLY”

## STEP II

- A) Start with two 4” x 4” x 13” corner posts, place the posts in position.
- B) Slide one 45” x 5½” x 1” side rail between the two posts.
- C) Repeat the same process with the other two 4” x 4” x 13” corner posts and another 45” x 5½” x 1” side rail.

Modular Raised Garden Bed 48x95x13



## STEP III

- A) Connect the two corner posts by sliding a 45” x 5½” x 1” side rail into each post.
- B) Slide the remaining four 45” x 5½” x 1” side rail into the posts. Make sure to place the 45” x 5½” x 1” side rail w/logo on the top, with logo facing right side up.

Modular Raised Garden Bed 48x95x26



## STEP IV MULTIPLE KITS

- A) See box labeling and/or image on right for multiple configuration options. Simply stack or expand in any direction. Posts can be left for future expansion or add a decorative cap to complete the look.

Note: Ground preparation is optional; we recommend leveling area under frame of bed before placing bed and filling with soil.

“L” Shaped Modular Raised Garden Bed 142x142x13



“U” Shaped Harvester Raised Garden Bed 189x189x13

