



CURTAIN PANEL INSTALLATION INSTRUCTIONS

- 1) Install curtain rod according to package instructions 2" – 4" above the top of the window frame
- 2) Remove panel from package
- 3) Use iron on low heat or steamer to remove wrinkles
- 4) Hang curtain panels on hardware
 - Grommet: feed rod through metal rings.
 - Rod Pocket: feed rod through rod pocket opening at top of panel.

Up to 63" L Panels typically fall below the window sill

84" L Panels typically reach the floor

95" L and longer Panels typically puddle on the floor

WINDOW WIDTH	PANELS NEEDED
Up to 29" wide	1 Panel
30" to 39"	1 or 2 Panels
40" to 48"	2 Panels
49" to 72"	3 Panels
73" to 96"	4 Panels
97" to 120"	5 Panels
121" to 144"	6 Panels