

CURTAIN INSTALLATION GUIDE

1. Measure the Window

Width: Measure window width. Curtain total width = $1.5 \times$ window width.

Height: Measure from top of window frame (or ceiling) to floor.

2. Mark Bracket Positions

Use level to mark a straight line; mark screw holes.

3. Install Brackets

Drill holes at marks. Insert wall anchors if needed. Screw brackets firmly; check level again.

4. Install Curtain Rod/Track

Rod: Slide rings first, then place rod into brackets, tighten screws.

Track: Click track into brackets; join multiple tracks with connectors.

5. Hang Curtains

Eyelet: Slide eyelets directly onto rod.

Pencil pleat: Pull header cords to gather; attach hooks to rings/track.

Tab top: Loop tabs over rod.

