

Privacy Window Film - Quick Install Guide

Steps:

1. Clean & Wet: Thoroughly clean glass. Spray generously with soapy water.
2. Peel & Stick: Peel back a small section of the liner. Apply to wet glass.
3. Slide & Align: Position film correctly—it slides easily on the wet surface.
4. Squeegee Out: Using the squeegee, push out air and water from center to edges.
5. Trim Edges: Use a utility knife to trim any excess film against the frame.

Note: Any cloudiness is normal and will disappear as it dries completely in a few days.