PERFORMANCE ACCESSORIES

TREADBOND INSTALLATION INSTRUCTIONS

SURFACE PREPERATION

- All substrates must be structurally sound, dry, solid and stable.
- Substrate should be clean and free of dust, dirt, oil, grease, curing agents, concrete sealers, loosely bonded toppings, loose particles, old adhesive residues, and any other substance or condition that may prevent or reduce adhesion.
- All surfaces must be level, even, flat and smooth.
- Concrete and cement-based levelers and patches must be fully cured and free of any hydrostatic and/or moisture problems.

PRODUCT APPLICATION WOOD/VINYL/HDF

Read all installation instructions thoroughly before installation.

1. Insert the TreadBond cartridge into a suitable caulking gun.
2. Cut the tip and puncture the inner seal.
3. Apply a serpentine bead of adhesive to the substrate.
4. Only apply as much adhesive as can be installed within 15 to 30 minutes under normal temperature and humidity conditions.
5. Curing time may be accelerated by a light misting of water over the extruded adhesive before installation of the materials to be bonded. (Do not puddle water.)