



A line drawing of an office chair with a high back, armrests, and a five-point base with casters. The chair is shown in a three-quarter view. Dimension lines with arrows indicate the height, seat width, and base width. The height is measured from the floor to the top of the backrest. The seat width is measured across the widest part of the seat. The base width is measured between the outer edges of the front and back casters.

**41.5 in.**  
*1.05 m*

**25.5 in.**  
*64.77 cm*

**25.25 in.**  
*64.13 cm*