

Caution: Turn off Power

1. Install in accordance with local electrical codes.
 2. Thread lamp holders into cover coating threads with sealing compound.
 3. Aim lamp holders to desired angle and tighten locknut.
 4. Wire the lamp holders to the supply lines in the box, white to white (neutral) and black to black (hot).
 5. Attach ground wire to green ground screw.
 6. Attach cover to the box, centering the gasket using supplied hardware.
 7. Close all unused holes with closure plugs.
 8. Seal all openings to comply with wet location installation.
-

Precaución: Desconecte el Suministro Eléctrico

1. Instale de acuerdo con la normativa de electricidad local.
2. Introduzca los portalámparas en la cubierta revistiendo los hilos con compuesto sellador.
3. Dirija los portalámparas al ángulo deseado y apriete la(s) tuerca(s) de seguridad.
4. Cablee los portalámparas hacia las líneas de suministro en el cajetín, blanco a blanco (neutro) y negro a negro (activo).
5. Fije el cable de tierra al tornillo verde de tierra.
6. Coloque la cubierta en el cajetín, centrando la empaquetadura utilizando los accesorios que se suministran.
7. Tape todos los agujeros no utilizados con los tapones de cierre.
8. Selle todas las aberturas para cumplir con la instalación en lugares mojados.

How-To Videos

Video de instrucciones

[youtube.com/HubbellElectricalSys](https://www.youtube.com/HubbellElectricalSys)

<Construction>

