



HOW TO INSTALL SpeedTiles

- 1** Please ensure that the wall where you want to install the SpeedTiles is clean and smooth.
- 2** Fill a 500 to 750 ml bottle with water and add 1 or 2 tea spoon (s) of mild dish detergent.
- 3** When installing the tiles, remove the protective paper the back side of the tile (pre-cut if required), spray a small amount of the water-detergent mixture on the adhesive and spread it with your hand over the whole surface. Adding the liquid will allow you to perfectly adjust the tile to the wall by delaying the adhesion process.
- 4** Once the tiles are in place, use a grout float to press the tiles, or a perfectly smooth and clean plank, as well as a rubber hammer, and gently hit the whole surface.
- 5** To finish, use a silicone of a matching color.

HOW TO CUT SpeedTiles

Table saw
Miter saw
Large utility knife
Wood chisel End
nipper pliers
Dremel
Angle grinder

If you use utility knife, work with a large metal ruler. Mark your mosaic. Place the ruler along the line and apply the blade against the side of the ruler and score without putting too much weight on the blade. With each new cut, add a little strength; after 5 to 6 scores, you will cut right through the mosaic. Regularly change the tip of the blade. If you use the wood chisel, insure that it's well sharpened.

