



Manufacturers Advanced Composite Materials, Automotive and Apparel
Specialty Fabrics, Bias Binding, Electrical Insulation,
Narrow Fabrics, P.V.C. Film, Construction, Survey & Safety Accessories

MUTUAL INDUSTRIES INC.

707 W. GRANGE STREET, PHILADELPHIA, PA 19120

800 523-0888

215 927-6000

FAX: 215 927-3388

CUSTOMER SERVICE LINE

WIRE BACKED SILT FENCE

Suggested Installation Instructions:

1. Excavate 6-8 inch deep trench.
2. Unroll product next to excavated trench.
3. Hammer wood stakes or metal t-stakes at desired spacing into ground using an 8-10 lb sledge hammer, use locking ties or zip ties to attach wire backed silt fence to fence stakes.
4. Ensure sufficient stake depth so that the colored bury line on the fabric is at the bottom of the trench.
5. Overlap end sections at least 1 foot and staple junctions to prevent silt infiltration.
6. Backfill trench to cover skirt of fabric and tamp soil either by foot or machine.