

# d-c-fix® Outdoor Floor Installation Instructions

\*For information regarding d-c-fix® Outdoor Floor, including videos and downloads please visit: [dcfixbrand.com/outdoorfloor](https://dcfixbrand.com/outdoorfloor)

**Basic tools and materials needed for installation**  
(available at your local hardware or DIY store)

- Tape
- Scissors
- Utility knife
- Hammer
- Adhesive compatible with PVC and exterior use
- Stapler
- Aluminum carpet strips w/stainless steel or other weather resistant nails to fasten around the deck perimeter or trim boards with drip edge (optional)

**NOTE:** Before proceeding, be sure that your deck is structurally sound. Do not install Outdoor Floor over broken boards or other defects that could cause hazards in using the deck/patio/porch surface. Apply adhesive according to adhesive manufacturers recommendation. This should include temperature range, surface prep and amount.

1. When applying d-c-fix® Outdoor Floor, it is recommended to clean the deck planks from any dirt, algae, mold, etc. as it could have a negative effect on the adhesion. It is also recommended to flatten any nail heads or screws that protrude from the surface.
2. Place d-c-fix® Outdoor Floor on the surface and roll out. Attach the starting end to your surface via stapler or another fastener. You will remove the fastener once the installation is complete. If using more than one roll or laying sheets next to each other, ensure the clean edge (the edge with no fabric) is installed over the top of the next sheet using a 1" overlap. Note: if using staples or other fasteners that will puncture the surface, make sure to seal or place in area that will not allow water to get in between the flooring and material and underlying substrate.
3. Roll the d-c-fix® Outdoor Floor back to the starting position.
4. Apply adhesive to the deck boards using a trowel to spread evenly, be careful not to over apply the adhesive as it may not cure properly.
5. Carefully unroll d-c-fix® Outdoor Floor applying pressure throughout the sheet to flatten the adhesive. Use a utility knife to cut out or around any permanent objects on the surface, such as post. Allow the adhesive to dry for 24 hours before resuming normal use. It can take up to 7 days for the adhesives to fully cure.
6. Apply adhesive on the vinyl underneath the 1" overlap seam. Apply to all areas of the seam and wipe away any excess immediately with a damp cloth. Failure to wipe away excess adhesive before curing may lead to imperfections of the surface
7. If using aluminum carpet strips to terminate, nail to the top of the d-c-fix® Outdoor Floor and use a utility knife to trim excess. Seal around the nails to prevent water infiltration.

