

NO-DIG LANDSCAPE EDGING®

RECOMMENDED TOOLS:

- Spade or shovel
- Rubber mallet
- Hack saw
- Gloves
- Protective eyewear

INSTALLATION INSTRUCTIONS

Always use proper safety precautions when installing aluminum edging.



- 1** Clear the installation area of all grass, loose soil, mulch, and other debris. Place aluminum edging on the cleared installation surface with the anchoring tabs facing the planting bed.



- 2** Use a rubber mallet to pound anchoring spikes (included in kit) through the aluminum tabs to secure the edging. If needed, additional anchoring spikes are sold separately.



- 3** Backfill to the top of the edging with mulch, river rock, wood chips, or other preferred ground cover. Assure tabs are completely covered with a thick layer of bedding material.

ADDITIONAL INFORMATION

Helpful Tips:

- Soil must be solid and level. Assure there is no debris between the edging tab and the dirt below.
- Weed fabric can minimize the spread of invasive weeds and grass. If desired, install fabric according to product directions. Then, place edging over the fabric and pound spikes through tabs and fabric.
- Certain conditions and landscape designs will require additional spikes, which are available in stores and online.

How To:

CONNECT

Overlap the final tab on each edging end and pound spike through both holes.

CREATE CORNERS

Bend the edging around a 2x4 piece of wood or other solid object to achieve the desired angle.

CUT

Carefully cut edging to the desired length using a hacksaw and protective gloves and eyewear.

CREATE CURVES

Aluminum edging bends easily to create curves. Carefully bend the edging to fit the landscape design.