

1. Attach 6 Brackets

Screw a bracket behind each hinge and 1 across from each hinge on the opposite side of door.



2. Draw Plumb Line

On the Hinge side of the wall, using a level, draw a perfectly plumb line down the drywall roughly ½" in from rough opening.



3. Place Door in opening

Line up the top hinge side bracket's reference notches with the "drawn" line from step 2. Screw the top hinge side bracket to wall. Use the same reference notch when screwing in the next 2 hinge side brackets. Door is now plumb/level.



4. Screw in final 3 brackets

Secure the opposite side of the door to the wall. Screw into place.



5. Mount Trim over the brackets

Complete the installation by nailing the casing/trim over the brackets to completely conceal them.



6. **For added support:** remove the center hinge screw from the hinges and replace with a 2" or longer screw (not included). The bracket has a clearance hole for the addition of these screws.