



200-Degree Door Viewer

Installation Instructions

DV-2014 series

1. Make sure it is of standard thickness, usually from 33mm - 55mm (1 3/8 inches - 2 1/6 inches).
2. Decide where you want the door viewer to go. It should be in the center of your door and about five feet from the ground. Once you've found your spot, mark an "X" there with a pencil.
3. Drill a hole to fit the diameter of the viewer on the "X" pencil mark through the door.
4. Insert the viewing scope and the barrel through each end of the hole. With a quarter (or any suitable tool) tighten the barrel and viewing scope until they fit snugly on the door.

Instrucciones de instalación del Mirilla

- 1- Evalúe su puerta. Ancho estándar es normalmente de 1 3/8 de pulgada a 2 pulgadas.
- 2- Decida donde desea que la Mirilla vaya. Debe estar en el centro de tu puerta y cerca de cinco pies del suelo. Una vez que haya encontrado su lugar, marque con una "X" con un lápiz.
- 3- Con una broca, taladre un agujero a través del espesor de su puerta.
- 4- Inserte la pieza de lente y luego el alcance de visión. Empuje el alcance de visión en el cilindro hasta que se ajuste cómodamente contra la pieza de lente.