

INSTRUCTION GUIDE



TAILPIECES (THREADED/DIRECT/SLIP JOINT)

1 Measure and cut the tailpiece to the desired length. Deburr the tube end.

2 Connect the tailpiece to the drain outlet.

a For threaded tailpieces: Wrap the threads with a thread seal tape.

b For flanged tailpieces: Slide the nut up the tube and insert the flanged washer into the flanged tailpiece.

c For slip joint tailpieces: Slide the nut then washer over the existing tailpiece. Slide the slip joint over the end of the tube.

3 Tighten the nut, being sure not to overtighten.

4 If there is a dishwasher branch, connect the dishwasher discharge hose to the branch on the tailpiece and secure with hose clamps.

5 Check for leaks. If leaks occur, tighten another $\frac{1}{4}$ turn.

6 Install the P-trap, connecting to the tailpiece outlet.

