

Universal Curtain Rod Installation Guide

Tools: Drill, level, tape measure, pencil, screwdriver.

1. Unpack and verify all parts.
2. Measure and mark bracket positions level above window.
3. Drill pilot holes if needed and install anchors.
4. Secure brackets with screws.
5. Place rod on brackets and tighten set screws if applicable.
6. Hang curtains and verify smooth operation.

Safety: Install into studs when possible. Observe product weight limits.