

MATCHING A DOOR TO BOSSJAMB™ HINGE AND LOCK PREP

Bossjamb™ Exterior Door Frame kits are factory routed for standard residential 4" hinges and lock strike hardware. They are ideal for blank exterior door slabs (doors that have not been routed for hinges and drilled for locks) up to 36" wide, 80" high, and 1-3/4" thick.

Refer to the hardware location illustration below to determine where to lay out hinges and lock bores on a blank door slab to match the hinge and lock prep on a Bossjamb™ Exterior Door Frame.

MEASURE FROM THE TOP OF THE DOOR TO:

