

Installation Instructions

- 1. Find Top of Sprinkler Head in yard or bed area**
- 2. Remove dirt to top of sprinkler head**
- 3. Lift riser and unscrew nozzle**
- 4. Thread on riser extension**
- 5. Add KAP-IT body over riser**
- 6. Snap onto top of sprinkler body**
- 7. Put on nozzle**
- 8. Turn riser clockwise to align**
- 9. Adjust nozzle and test**