



## How to Install Your Curtain

---

- 1 Mount your curtains close to the ceiling
- 2 Extend rod 5" to 6" on each side of the window
- 3 To achieve proper window coverage, the total width of the curtain should be at least 1.5 times the width of the window

## Styling Tip

---

- A Clean Look: Use 63" so curtains lay on the window frame
- B Casual Look: Use 84" so curtains fall 6" below the window frame
- C Polished Look: Use 96" so curtains fall 1" above floor