

Measuring & Order Guide

MEASURING FOR HARDWARE

The rod width you specify on your order does not include the width of the finials on each end. Finials add $\frac{1}{2}$ " to $9\frac{1}{2}$ " on each end, depending upon the style. Hardware is usually ordered same size as drapery. For exact finial widths by style, call Customer Service.

HEIGHT SUGGESTIONS FOR PANELS AND DRAPERIES

- 1** VALANCE - For panel styles that will be used as a top treatment or valance, we recommend approximately 10-20" for length.
- 2** SILL LENGTH - A great choice for a window in a recess or above furniture, or for one that is opened frequently.
- 3** APRON LENGTH - For ideal proportions, this look should fall about 4" below sill.
- 4** CAFÉ LENGTH - Panels usually measure $\frac{1}{2}$ " of the window length. These styles are especially useful for kitchens, allowing both natural light and privacy. Best hardware for these are Petite Rods (less than 1" in dia.) for smaller size windows or Medium Rods (1" in dia) for bigger windows.
- 5** FLOOR LENGTH - Treatments that will be opened and closed regularly

