

Preparation

1. The wall surface should be clean, dry, and smooth, and free from mildew.
2. Wall surfaces should be primed with a wallcovering primer.

Hanging Instructions

1. These wallcoverings are inspected and tested - however, they should be checked for defects before hanging. We will replace defective merchandise through your dealer, but assume no responsibility for labor charges for the application or removal of any wallcovering. The hanging of more than 3 strips constitutes acceptance of the product. On plains and textures, we recommend reverse hanging the strips.
2. Apply a lightweight pre-mixed vinyl adhesive to the wallcovering, carefully following the paste manufacturer's instructions. Please ensure sufficient paste is applied to the edges of the wallcovering
3. Fold the strip slowly, glue on glue, by taking both ends to the middle of the strip (booking). Let it sit for 3-5 minutes.
4. For non-matched patterns, reverse hang alternate strips. After 3 strips are hung, stand back and inspect. If the effect is not desirable, re-hang strip #2 without reversing.
5. **IMPORTANT:** Wash adhesive completely from the surface of the wallcovering immediately after hanging each strip. Any adhesive left on the wallcovering can attack the surface printed inks and cause them to flake.

465 Devon Park Drive Wayne, Pennsylvania, United States 19087