



To assure that product adheres to window:

- 1) Window must be clean.
- 2) Must be a cool, smooth surface with no texture of any kind.
- 3) Non-textured side of Artscape must be against the glass.
- 4) Do not allow film to touch window frame.