



From Power Source:

1. White connects to the white wire from the motor.
2. Black connects to the black lead on the t-stat.
3. Green connects to the green ground screw on the PT6 casing.

From Fan Motor:

4. Black (w/ White Stripe) goes to the remaining black lead on the t-stat.
(Ensure connections are as shown)

NOTE: Follow all Electrical Codes when installing. Remove power from the circuit before connecting wires.