



## QUICK MOUNT REFLECTORS

INSTALLATION INSTRUCTIONS  
INSTRUCCIONES DE INSTALACION  
CONSIGNES D' INSTALLATION

---

### READ ALL WARNINGS AND INSTRUCTIONS BEFORE INSTALLATION

#### INSTALLATION INSTRUCTIONS

1. SELECT A SUITABLE MOUNTING LOCATION.
2. CLEAN THE MOUNTING LOCATION SURFACE OF DIRT, GREASE, AND DEBRIS.
3. REMOVE THE PROTECTIVE FILM FROM THE ADHESIVE PAD ON THE BACK OF THE REFLECTOR.
4. FIRMLY PRESS THE REFLECTOR INTO PLACE.

### LEA TODAS LAS INSTRUCCIONES Y ADVERTENCIAS ANTES DE REALIZAR LA INSTALACIÓN

#### INSTRUCCIONES DE INSTALACIÓN

1. ELIJA UNA UBICACIÓN ADECUADA PARA EL MONTAJE.
2. ELIMINE LA SUCIEDAD, GRASA Y RESIDUOS LA SUPERFICIE DE MONTAJE.
3. RETIRE LA PELÍCULA PROTECTORA DE LA ALMOHADILLA ADHESIVA EN LA PARTE POSTERIOR DEL REFLECTOR.
4. PRESIONE FIRMEMENTE EL REFLECTOR EN SU LUGAR.

### LIRE TOUTES LES MISES EN GARDE ET CONSIGNES AVANT L'INSTALLATION

#### INSTRUCTIONS POUR L'INSTALLATION

1. CHOISISSEZ UN EMPLACEMENT DE MONTAGE APPROPRIÉ.
2. NETTOYEZ LA SURFACE DE L'EMPLACEMENT DE MONTAGE EN PRENANT SOIN D'ENLEVER LA SALETÉ, LA GRAISSE ET LES DÉBRIS.
3. RETIREZ LA PELLICULE PROTECTRICE DU COUSSINET ADHÉSIF À L'ARRIÈRE DU RÉFLECTEUR.
4. APPUYEZ FERMEMENT SUR LE RÉFLECTEUR POUR LE FAIRE ENTRER EN PLACE.

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9216 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT [WWW.TOWSMART.COM](http://WWW.TOWSMART.COM).



Winston Products Company  
TOWSMART.COM  
WINSTON PRODUCTS, LLC.  
30339 Diamond Parkway  
Cleveland, OH 44139