

## BALL MOUNT

### INSTALLATION INSTRUCTIONS

**⚠ WARNING:** Read and observe all warnings, instructions, and capacity limitations before using this product. Failure to comply with this warning and the associated instructions and capacity limitations may result in serious personal injury and/or significant property damage.

1. Insert the Ball Mount into the Hitch receiver tube.
2. Align Hitch Pin holes.
3. Insert a Hitch Pin or Receiver Lock of a corresponding diameter, into receiver tube hole so that the end is completely out of the other side of tube, exposing the Hitch Pin hole or groove or lock end.
4. Insert the straight leg of the Hitch Pin Clip into the Hitch Pin hole or groove until it can go no further, or snap on the end of Receiver Lock so that it is locked.
5. Install correct Hitch Ball so that the diameter matches the Coupler size:
  - The shank should be long enough to exceed the Ball Mount bar thickness and a tightened nut by 2-1/2 threads.
  - The diameter of the shank should match the tongue hole diameter.
6. Torque nut according to 250 ft. lbs.

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9215 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT [WWW.TOWSMART.COM](http://WWW.TOWSMART.COM).