

D300-1, D301-1, D302-1

INSTRUCTIONS:

1. To remove old shower arm and flange place strap wrench around arm and turn counter-clockwise.

Pull old flange off.

2. Apply pipe joint compound or PTFE tape to new shower arm threads. Push new flange on and thread into fitting in wall. Turn arm clockwise until straight and tight.

INSTRUCCIONES:

1. Para sacar el brazo existente de la ducha tomarlo con una llave para tubos y hacerlo girar en sentido antihorario. Sacar la brida existente.

2. Aplicar sellante de rosca o cinta de Teflon™ en los filetes de la rosca del brazo nuevo. Luego colocar la brida nueva y enroscarlo en el tubo de la pared. Gire el brazo en sentido de las manecillas de reloj hasta que esté derecho y ajustado.

