

Plastic Lawn Edging Instructions

Step 1

Clear the installation area of all grass, loose soil, mulch, and debris. Place edging in desired shape on cleared surface with anchoring tabs facing the planting bed.

Step 2

Hammer anchoring spikes through tabs to secure the edging. Typical installations require one spike every 10 tabs. Additional spikes are available separately.

Step 3

Backfill to the top of the edging with mulch, river rock, or other ground cover. Assure tabs are completely covered with a thick layer of bedding material.

USING THE CONNECTOR

Place the connector on top of the end tabs of each piece. Spike through the holes in the connector and each of the end tabs.

CUTTING THE EDGING

Cut edging at the midpoint between the anchoring tabs using hand snips or a fine tooth saw.