

INSTALLATION INSTRUCTIONS

1. Place nuts **(A)** and washers **(B)** onto tailpiece. If using slip joint elbow, place nuts **(A)** and washers **(B)** onto wall tube as well. Use reducer washer **(E)** if tailpiece is 1-1/4 in.
2. For slip joint elbow, attach elbow **(C)** to J-bend **(D)** and wall tube. For solvent weld elbow, follow instructions on PVC solvent cement to connect elbow **(C)** to wall tube. Once solvent weld process is complete, attach J-bend **(D)** to tailpiece and elbow **(C)**.
3. Tighten nuts. **CHECK FOR LEAKS**

INSTRUCCIONES DE INSTALACIÓN

1. Coloca las tuercas **(A)** y las arandelas **(B)** en el tubo de conexión. Si se está usando un codo de junta deslizante, también coloca las tuercas **(A)** y las arandelas **(B)** en el tubo de la pared. Usa la arandela reductora **(E)** si el tubo de conexión es de 1-1/4 pulg. (3.17 cm).
2. Para el codo de junta deslizante, fija el codo **(C)** al codo en J **(D)** y al tubo de la pared. Para soldar el codo por solvente, sigue las instrucciones del cemento por solvente de PVC para conectar el codo **(C)** al tubo de la pared. Cuando hayas terminado el proceso de soldadura por solvente, fija el codo en J **(D)** al tubo de conexión y al codo **(C)**.
3. Aprieta las tuercas. **VERIFICA QUE NO HAYA FILTRACIONES**

