

Animal Barrier Fence Instructions / Assembly

1. Preparation Before Installation

Check that all parts are complete: 10 fence panels, 1 wire cutter, 20 snaps, and 20 cable zip ties.

Choose a flat outdoor area (path edge, lawn, or garden border) and clear any debris (stones, weeds) from the installation site.

2. Panel Connection (2 Options)

Option 1: Snap Interlock

Take two fence panels and align the snap on one panel with the corresponding slot on the other.

Press the snap firmly until it clicks into place, ensuring the panels are tightly connected.

Repeat to link all 10 panels into your desired shape (round, hexagonal, triangle, or straight).

Option 2: Cable Tie Connection

Place two panels side by side and wrap a cable tie around the overlapping metal wires of the two panels.

Pull the tie tight to secure the panels, then use the wire cutter to trim the excess length of the tie.

Add 1-2 more ties per panel joint for extra stability, then continue connecting all panels.

3. Ground Insertion

Hold the connected fence section vertically at the installation position.

Push the angled bottom of the fence into the ground firmly—apply even force to avoid bending the panels.

Adjust the fence's position and straightness as needed; ensure the top edge stays level.

4. Post-Installation Check & Maintenance

Check all connections (snaps or ties) to confirm they are secure; re-tighten or replace loose ties if necessary.

Wipe the fence surface with a dry cloth regularly to remove dust; rinse with water if stained (avoid harsh cleaners).

After heavy rain or strong winds, check if the fence is tilted and reinsert or adjust it promptly.

Note

Do not force the fence panels to bend beyond their natural flexibility to prevent metal breakage.

Keep the wire cutter and extra ties in a dry place for future maintenance.