

VaporBlock 6 mil Polyethylene Film Installation Guide



Rolls out to 150 Sq Ft
6 mil x 6' (72") x 25'

Cal-Flor VaporBlock helps protect floor from harmful vapor emissions. Using film over rough subfloors when installing pad-attached flooring allows the flooring to smoothly expand and contract, reducing lateral friction.

Installation

- 1) Always follow the flooring manufacturer's installation instructions with respect to preparing and leveling the subfloor.
- 2) Unroll VaporBlock PE film. Cut film about 2 inches longer than wall to ensure full moisture protection of the flooring.
- 3) Overlap adjoining seams by 3". Use attached positioning tape to help align.
- 4) Tape tears, cuts and end seams with packaging tape to ensure full moisture protection.