## COLMET®

DEFINED BY STEEL®



## **TOOLS FOR INSTALLATION**

## Hacksaw Long Handled Pliers Heavy Hammer Gloves & Glasses Solid Piece of Scrap Wood

## **EASY INSTALLATION**



SNAP.

Break away the two stakes on each end of the edging.



PLACE.

Hand-form the edging to shape, then trench or pound edging directly into the ground.



STAKE.

Drive down stakes to connect and secure each section. Stakes should be flush or slightly lower than the edging.

