

## **Impact Sprinkler on Tripod Base Installation Guide**

### **1. Unpack and Inspect:**

Lay out all parts from the package. You should have: tripod legs (3), brass impact sprinkler head, gooseneck connector with filter, and locking clips/knobs.

### **2. Assemble the Tripod Stand:**

Extend the tripod legs to your desired height (Low, Medium, or High). Align the holes on the leg sections and secure each leg at the chosen height by pressing the quick-lock buttons or tightening the provided knobs firmly. Ensure all three legs are locked at the same height setting for stability.

### **3. Attach the Sprinkler Head:**

Screw the brass impact sprinkler head clockwise onto the top threaded outlet of the tripod stand. Hand-tighten securely. Do not over-tighten with tools.

### **4. Connect Your Hose:**

Ensure the rubber O-ring filter is inside the gooseneck connector. Connect your standard 3/4" garden hose to the gooseneck inlet. Then, screw the gooseneck connector onto the inlet at the base of the tripod stand. Hand-tighten both connections securely.

### **5. Position and Adjust:**

Place the assembled sprinkler on a flat, stable surface in your desired watering area. Point the sprinkler head in the direction you wish to start watering. To adjust the spray pattern (full or partial circle), rotate the adjustment screw or clip on the sprinkler head. For distance, adjust the deflector plate.

### **6. Test Operation:**

Slowly turn on your water supply to the recommended pressure. Observe the rotation and spray pattern. Make minor adjustments to the head or water pressure as needed. The tripod should remain stable during operation.

### **Important Notes:**

Always follow the recommended water pressure range (20-80 PSI) for optimal performance.

The built-in filter helps prevent clogging but periodically check and clean it if you have sandy water.

For storage in freezing conditions, drain all water from the sprinkler and hose.