

Window Curtain Installation Guide

Step 1. Open window curtain package

Step 2. Unscrew curtain rod

Step 3. Insert curtain grommets into curtain rod

Step 4. Reinsert curtain rod in front of window, secure rod with screws

Step 5. Enjoy brand new window curtains.