

HOW TO RESTORE YOUR DECK

Completely transform your deck in one weekend with a few coats of Restore.



Is your deck looking tired after the long winter? It's time to snap it back into shape with Restore! Here's how you can restore even the most heavily-worn deck just in time for barbecue season.

ITEMS

- Restore Deck & Concrete Cleaner
- Restore Deck Start Wood Primer
- Restore 10x Advanced – Graywash
- 3/8" Nap Roller
- Restore 9" Honeycomb Roller
- Restore 4x Deck Coat – Graywash
- Paint Stick
- Metal Paint Tray
- Paint Scraper
- Hammer
- Drill

1. PREPARE: Before you start, read through all instructions on each of your Restore products. Make sure that there is no rain forecasted in your area for the next 48 hours, and that the temperature will not drop below 50 degrees, even overnight.

2. CLEAN: Following the label's instructions, wash your deck with **Restore Deck & Concrete Cleaner**, and then let it dry completely. Check your deck for any loose screws, nails, or boards, and replace them as needed.

3. PRIME: Before you start to prime, tape and mask off any siding or portions of your deck that you want to protect from paint. Always stir your paint and primer according to the label's instructions. Use a paint brush to apply a generous, even coat of **Restore Deck Start Wood Primer** to your railings, balusters, and posts. Then, use your 3/8" nap roller to roll a thick coat onto the entire deck floor. Let the primer dry completely for at least two hours. It will go on milky, but dry clear.

4. COAT: Use a paint brush to apply two even coats of **Restore 4x Deck Coat** to your deck's railings, posts, and balusters. Allow 4-6 hours in between coats (the paint should not be tacky).

Next, use your **Restore 9" Honeycomb Roller** to apply an even coat of **Restore 10x Advanced** to the deck's floor, working on 1-2 boards at a time. While you apply Restore 10x, roll in one direction with slight downward pressure, and use a paint scraper to remove excess coating in between the boards. Let your first coat dry for 4-6 hours (it should not be tacky), and then apply a second coat.

5. FINISH: Let your final coat dry completely for 48 hours. Once it's dry, replace your furniture and enjoy your new deck!

 **RUST-OLEUM®**