

Over-the-Toilet Storage Shelf Installation Guide

Package Contents (Please Verify First)

H-shaped metal frame, 4 P2 particleboard shelves, 1 storage basket, 3 removable hooks, 1 toilet paper holder, wall-fixing nails, anti-slip feet, matching screws, and assembly tool.

Installation Steps

- 1. Preparation:** Clear a flat, spacious area around the installation spot (over the toilet) to avoid part loss. Check all components for completeness and damage before assembly.
- 2. Assemble the Metal Frame:** Connect the H-shaped metal poles using the provided screws. Use the included tool to tighten all joints firmly. Attach the X-shaped crossbar to the frame symmetrically to enhance stability.
- 3. Install Shelves:** Place the particleboard shelves into the designated slots on the frame. The three middle shelves are adjustable—adjust their height according to your storage needs, then secure them with screws to prevent sliding. Ensure all shelves are level.
- 4. Attach Accessories:** Fix the storage basket to the pre-marked position on the frame (anti-fall design ensures item safety). Mount the removable hooks and toilet paper holder on the frame sides as desired. Stick anti-slip feet to the bottom of each frame leg to protect the floor and improve stability.
- 5. Final Securing:** Move the assembled shelf over the toilet and position it evenly. Use wall-fixing nails to anchor the top of the frame to the wall, preventing tipping or shaking. Double-check that the shelf is stable and all parts are tightly fastened.

Important Notes

- Maximum load-bearing per shelf is 30 lbs—do not exceed this limit to avoid damage.
- For indoor use only; keep away from sharp objects to protect the lacquered finish.
- Use wall-fixing nails mandatory to ensure safety, especially in humid environments like bathrooms.
- Avoid using harsh chemicals to clean the shelf; wipe with a damp cloth gently.