

# Garage Instant Screen™ Instructions

## Attach with Velcro™

1. Peel off backing from Velcro™ strip
2. Place Velcro™ strips evenly spaced over the top of the opening.
3. Attach Instant Screen™
4. Place rods in bottom of the screen through the premade slots with butterfly ends on the outside and insert two rods together.



## Attach with Screw Hooks

1. With a pencil through the eye holes in the Instant Screen™, mark spacing on the opening you will be attaching the hooks.
2. Screw the hooks in your marking, which should be evenly spaced across the opening. If screwing into sheetrock, use the sheetrock anchors provided.
3. Attach the Instant Screen™.
4. Place rods in bottom of the screen through the premade slots with butterfly ends on the outside and insert two rods together.

