

MDS17
White
Blanco

Made in USA/Hecho en E.U.A.



Warning: This product may contain a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.



Installation:

1. Measure width and height of door.
2. Shorten strips if needed.
3. Remove the existing seal out of the kerf (groove).
4. Make sure area is clear of any dirt or grease.
5. On the lock side of the door frame, install the long *magnetic* strip by pressing the flat end into the kerf.
6. On the hinge side of the door frame, install the *non-magnetic* strip by pressing the flat end into the kerf.
7. Across the top, install the short *magnetic* strip by pressing the flat end into the kerf.
8. For best results, miter corners where pieces meet.