

Universal Curtain Rod Measurement Guide

Measure window width. Add 6-12 inches to determine recommended rod length (3-6 inches beyond each side). Mount brackets about 4-6 inches above the window frame unless design requires otherwise. Verify wall clearance for finials and curtain stack-back. Confirm rod diameter and weight capacity match your curtains before installation.