

Installation Guide for Wall-Mounted Rustic Coat Rack

Package Contents: 1 brown pine plank, 8 triple-hooks, 16 short screws, 4 long screws, 4 drywall anchors, 1 installation instruction (already included in package).

Tools Needed (Not Included): A drill, a screwdriver (matching screw sizes), a level, and a pencil for marking.

Installation Steps: 1. Choose a suitable location on the wall (entryway, bedroom, etc.) and use a level to mark the position of the pine plank to ensure it is straight. 2. According to the plank's pre-drilled holes (if any) or the hook mounting positions, mark the screw holes on the wall with a pencil. 3. For drywall surfaces, drill pilot holes at the marked positions, insert drywall anchors, and tap them flush with the wall. For solid walls (wood, concrete), skip the anchor step and drill pilot holes directly. 4. Align the pine plank with the marked holes, use long screws to secure the plank firmly to the wall; tighten screws until the plank is stable and does not wobble. 5. Take the triple-hooks, align them with the pre-drilled holes on the plank, and fasten each hook with 2 short screws. Ensure all hooks are tightly fixed to avoid loosening.

Usage Adjustment: The coat rack consists of two hinge-connected pieces. To use as a single large rack (32 inches overall length), keep the two pieces unfolded and aligned. To split into two sections, gently fold along the hinge and reposition each section on the wall as needed (for different heights).

Notes: Each triple-hook holds up to 30 lbs; avoid overloading. Ensure screws are fully tightened to prevent falling. Install on a solid wall for better stability; drywall anchors are for drywall only. Keep installation tools away from children.