



1. Measure the length of the wall where the quarter round will be installed.
2. Cut the quarter round with a miter saw, circular saw or hand saw to the necessary length.
3. Place the quarter round against the wall or wallbase and test the fit.
4. Nail the quarter round into the wall or wallbase with finishing nails.
5. Fill nail holes with coordinating putty.