

Installation

1. Let cable Pass through the hole of nail
2. Adjust the location of nail
3. Use more nails if necessary
4. Knock nails into the wall

