

# FAUX EZ™ (Original)

## Directions for Use

### May be used on:

Any existing soundly adhered, nearly white interior primed/sealed surface such as painted wood, metal and vinyl coated cabinets etc. in good condition.

### Product Coverage:

Step One liquid brush-on base coat:

8oz. liquid base covers about 20 square feet.

Step Two Aerosol

16 oz. aerosol covers about 20 square feet for light colors like oak or pine. Use addition Step Two for darker colors such as Walnut or Mahogany.

### Things you will also need:

1. Krud Kutter or TSP
2. Blue tape and paper
3. Cleaning sponge
4. Sanding sponge

Also see video on Directions for Use.

## Surface Preparation:

### DO NOT USE STEEL WOOL!

1. Sand rough surfaces until smooth. If surface is already smooth, no sanding is required but surface must be cleaned with Krud Kutter or TSP and rinsed well.
2. Fill holes and caulk as needed and sand smooth again.
4. Tape off adjoining areas within spraying distance, (about 4 feet) and cover floors and ceiling.

## Applying FAUX EZ™:

1. Stir contents of liquid 'Step 1' thoroughly.
2. Apply 'Step 1' using your chip brush, leaving streak marks on the finish. Apply very sparingly. Work very quickly. Don't try to make it cover solid. You want streaks to look like grain, so be sure to brush the same direction that the grain of real wood would go. If you have a drip or run, brush it out immediately! Excessive brushing is not recommended. Remember that real wood is not perfect. That's what makes it beautiful!
3. Allow 30 minutes for drying at normal temperature and humidity. Remember that FAUX EZ™ is water-based and may take longer dry time in high humidity.
4. Repeat the application of 'Step 1' and let dry for 30 minutes or more.
5. Shake Step 2 aerosol for at least 1 minute.
6. Hold can upside down and spray onto masking paper to clear nozzle.
7. Holding can upright at a slight angle spray onto masking paper to get used to spray pattern. Put can into motion before pressing release tip. Practice a little bit.
8. Spray with a steady motion. Make only two passes (back and forth).
9. Repeat spray application for deeper color tones.
10. For richer depth of color, spray more around the edges.
11. You can also see in the video how to enhance the appearance of panels in doors.
12. Clean up equipment and spills immediately with soap and water.

