

Soffit Vent Installation

Instructions:

1. The vent can be installed by friction fit or by screws or rivets.
2. For friction fit make sure holes are drilled to exact dimensions then insert vent and the serrations on the collar will hold it in place.
3. For screws or rivets pre-drill the flange for the size of rivet or screw, then fasten in place to wood or plastic soffit.

