

THE

HERCULINER ADVANTAGE

- High Scratch & Impact Resistance
- Great Adhesion to both Steel or Aluminum Truck Beds
- Heavy Textured Skid Resistance
- Excellent Chemical & Water Resistance

**EASY TO
INSTALL**

SCAN FOR VIDEO



PREP

IMPORTANT: This step is critical to achieve maximum adhesion and durability.

CLEAN: Clean any debris out of the bed and wipe down with a household detergent or solvent to remove any oils or grease from the surface. Remove any caps, covers or trim from the bed you don't want coated.

TAPE: Use tape to mask off the edges and plug any drain or bolt holes.

SAND/SCUFF: For Herculiner to properly adhere, the bed needs to be thoroughly sanded/scuffed to remove any gloss or visible rust. We recommend a mouse or orbital sander with no higher than 100 grit sandpaper. After sanding, use a blower or broom to remove particles. Wipe the bed again with solvent and allow to completely dry.

1 QT

THIS CAN COVERS
15 SQUARE FEET
WITH 2 COATS

APPLY

MIX: We recommend wearing disposable gloves. Open the can of Herculiner and use a stir stick or a drill with a paint mixing attachment to mix the material until texture and consistency is uniform. Pour material into a paint tray to begin use.

BRUSH: Use a brush to dab Herculiner into seams and corners where the rollers won't reach.

FIRST COAT: Using a foam stipple roller and frame, apply the first coat of Herculiner to the back panel (near the cab) and the side panels of the bed. Then, starting from the back of the bed and working towards the tailgate, apply the Herculiner onto the truck bed floor using even strokes. Occasionally mix the material in the can or tray during application to prevent settling. Once completed, let dry for 1-4 hours, or until no longer tacky. Discard the used roller.

SECOND COAT: After the first coat is dry, apply the second coat. Touch-up any uneven areas with remaining Herculiner. Remove the tape as soon as you're done with the second coat to avoid tearing or sticking.

DRY

Herculiner is normally ready for light use in 12 hours, and heavy use in 24-48 hours. It will cure slower in cold, dry weather and faster in warm, humid weather.

NOTES:

- Two coats are required for adequate coverage and performance.
- Herculiner can be applied between 32°F and 95°F (0°C and 35°C)

HERCULINER CAN ALSO BE APPLIED TO:

- Metal • Concrete • Wood • Fiberglass
- Most Plastics Including PVC • Rubber



A J-B WELD COMPANY