

DOOR SET

Wood & Vinyl Clad Foam

Installation:

1. Measure door width and height.
2. If needed, shorten.
3. Across top, press the short strip on door stop so the vinyl presses firmly against the door when closed.
4. On sides, press long strips on door stop so the vinyl presses firmly against the door when closed.
5. screw or nail into place.
6. Make sure top strip fits snugly against side strips.

Madera y espuma cubierta de vinilo

BURLETE PARA PUERTA

Instalación:

1. Mida el ancho de la puerta.
2. Corte si es necesario.
3. A lo largo del tope, coloque la tira corta en la moldura de manera que el vinilo quede firmemente en contacto con la puerta cuando esté cerrada.
4. En los lados, coloque las tiras largas en la moldura de manera que el vinilo quede firmemente en contacto con la puerta cuando esté cerrada.
5. Atornilleo clave en su lugar.
6. Asegúrese que la tira corta quede bien ajustada entre las tiras largas.

TOOLS NEEDED:
HERRAMIENTAS NECESARIAS:



Follow Us @FrostKing
or www.frostking.com



Thermwell Products Co., Inc.
Mahwah NJ 07430 | Sparks NV 89431

Need help or information
about any Frost King product?
Call **1-877-FROST 20**
3 7 6 7 8

For videos, instructions, hints and tips
visit www.frostking.com/instructions