



20 FT NO-DIG SCALLOP EDGING KIT EASY TO INSTALL

INSTALLATION INSTRUCTIONS

Always use proper safety precautions when cutting and spiking edging. Protective eyewear and gloves are recommended during installation.



- 1** Clear the installation area of all grass, loose soil, mulch, and debris. Place edging in desired shape on cleared surface with anchoring tabs facing the planting bed.



- 2** Hammer spikes through tabs to secure the edging. Every installation is different, if additional anchoring is required, additional spikes are sold separately.



- 3** Backfill to the top of the edging with mulch, river rock, or other ground cover. Assure tabs are completely covered with a thick layer of bedding material.

USING THE CONNECTOR



Place the connector on top of the end tabs of each piece. Spike through the holes in the connector and each of the end tabs. Anchoring spikes should be hammered only to the top of the edging tab. Hammering the spike to the point the tab bends will result in wavy edging.

HELPFUL TIPS & INFORMATION

Site Preparation:

Soil must be solid and level. Assure there is no debris between the edging tab and the dirt below. Compact the cleared soil prior to installation to reduce spike movement from shifting ground and frost heave.

Weed fabric can minimize the spread of invasive weeds and grass. Install fabric according to product directions, then place the landscape edging over the fabric and hammer spikes through the tabs and fabric.

Allow the edging to relax in the sun prior to installation to allow for thermal expansion. Installing the edging when expanded and pulling tightly can reduce undesirable waves in straight installations.

Installation:

Enough anchoring spikes are included to accommodate a typical installation. Certain conditions and landscape designs will require additional spikes, which are available in stores and online.

Edging can be cut with garden shears or a fine tooth saw. Cut edging at the midpoint between anchoring tabs, if possible.

Backfill sufficiently to the top of the edging immediately after installing the edging. Heavy bedding materials, such as rock and mulch, tend to perform best.

