




Model # XMB2008 - STAND
Item # 1004095675/1004093029
Item # 1004095676/1004095656
Item # 1004095679/1004095658
Item # 1008284457/1008254712
Item # 1008254725/1008289657

USE AND CARE GUIDE

Granbury Classic Platform Bed - Full/Queen/King



Questions, problems, missing parts?
Before returning to the store, call Customer Service.
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

*We appreciate the trust and confidence you have placed in Style Well through the purchase of this Granbury Classic Platform Bed - Full/Queen/King .
We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your
home improvement needs. Thank you for choosing Style Well!*

Table of Contents

Table of Contents	2
Safety Information	2
Warranty	2
1 Year Warranty	2
What is Covered	2
What is Not Covered	2
Pre-assembly	3
Planning Assembly	3

Tools Required	3
Hardware Included	3
Pre-assembly (continued)	4
Package Contents	4
Assembly	5
Maintenance	11
Care and Cleaning	11

Safety Information



DANGER

- Keep small parts away from children during assembly.
- Read and follow instructions carefully.



WARNING

- TO GUARANTEE THE SAFE USE OF THIS PRODUCT, FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- Adult assembly required.
- Small parts may present choking hazard prior to assembly.



CAUTION

- Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.). Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- DO NOT USE SUBSTITUTE PARTS.
- This product should only be used on a flat, level surface.
- Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.
- Assembly requires two people; assembly alone may cause injury.
- Before using the product be sure that it is completely and properly assembled.
- During assembly children should be kept away from the product to avoid possible risk of injury.
- Regularly check screws to ensure they are tightened securely .

Warranty

1 YEAR WARRANTY

WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED


This warranty does not cover commercial use, acts of nature, and abusive use.

Pre-assembly

PLANNING ASSEMBLY

- Remove all Packaging materials , staples and packing straps form the carton .
- Refer to Parts List and Hardware List , and ensure parts and hardware are correct before assembly .
- Contact customer service for missing parts .
- Place all wooden parts on a clean , flat , and soft surface (e.g.carpet or rug) to prevent scratch and damage to parts .


TOOLS REQUIRED



HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	Screw Ø8*50mm	10
BB	Washer	21
CC	Allen key	1
DD	Screw Ø8*35mm	7
EE	Screw Ø6*90mm	4
FF	Screw Ø6*23mm	4
GG	Wooden dowel	8
HH	Screw Ø8*20mm	4

Pre-assembly (continued)


PACKAGE CONTENTS




Part	Description	Quantity
A	Headboard	1
B	Headboard Left Leg	1
C	Headboard Right Leg	1
D	Headboard Support Bar	1
E	Footboard	1
F	Footboard Right Leg	1
G	Footboard Left Leg	1
H	Left Sideboard	1
I	Right Sideboard	1
J	Slat	2
K	Center Support	1
L	Metal Legs	3

Assembly

- 1** Place footboard left leg (G) and right legs (F) with the 4 holes facing up as shown and insert wood dowel (GG) into the middle two holes.




- 2** Take out the left sideboard (H) and right sideboard (I) and insert wood dowel (GG) into the side two holes as shown photos.




Assembly

3 Assemble legs to headboard.

- Take out the headboard (A) ,headboard left leg (B) ,headboard right leg (C) and put the headboard (A) exterior side facing up as shown.
- Fasten leg (B) and leg (C) to headboard (A) with screw (AA) fitted with washer (BB).Use allen key (CC) to drive(AA).




4 Turn assembled headboard over,fasten the headboard support bar (D) to the 2 holes in leg (B and C) with srew (DD) fitted with washer(BB).Use allen key(CC) to drive (DD).




Assembly

5 Assemble legs (F and G) to footboard (E).

- Place footboard(E) with the interior side facing up as shown.
- Attach leg (F) and leg (G) from step 1 to footboard (E) via wood dowels, and fasten with screw (AA) fitted with washer (BB). Use allen key (CC) to drive (AA).




6 Fasten metal leg (L×3) to center support (K) with screw(DD) fitted with flat washer (BB) .Use allen key (CC) to drive (DD) .



Assembly


7 Assemble sideboard (H and I) to footboard (E)

- Position footboard (E) vertically.
- Attach sideboard (H and I) to footboard (E) by fitting the bracket hooks on (H and I) into the bracket slots on footboard (E).




8 Assembly bed frame from step 7 to the headboard from step 4.

- Insert the screw (FF) to the 2 holes on sideboard (H and I).
- Fasten the sideboard (H and I) to the headboard legs (B and C) with screw (EE). Use allen key (CC) to drive (EE).



Assembly


- 9** Attach cent support (K) to footboard (E) and headboard support bar (D) with screws (HH) fitted with washer (BB) by allen key (CC).



Assembly

10 Lay the 2 sets of slat (J) to fit on the rail on the sideboards.

- Check and ensure that the designated slat on each set is firmly affixed to the rail on the sideboard.
- Remove adhesive covering from the 2 pieces of slate.
- The assembly of the bed platform is complete.



Maintenance

- ☐ Keep the product away from direct heat and sunlight .
- ☐ Prolonged exposure to heat sources may cause scorching, or even cause color to fade .
- ☐ Regular vacuuming or light brushing helps to remove dirt and prevent soil build-up, which increases the appearance of wear .
- ☐ Periodically (every 90 days) make sure that the screws are fully tightened .

Care and Cleaning

- ☐ Handle with care.
- ☐ Use a slightly damp cloth to clean the product. Do not use bleach or use abrasive cleaning material .
- ☐ Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts are damaged or broken .
- ☐ Never allow any kind of liquid to remain on your furniture .
- ☐ Absorption can make wood warp or delaminate .
- ☐ Do not place hot items (e.g. hot drinks) directly onto the wood surface.
- ☐ Do not drag and /or pull the furniture .
- ☐ Never use harsh chemicals or solvents on your product as this may damage the metal .
- ☐ Marks and stains from pens, crayons and ink markers are difficult to remove. In the event that your products become permanently stained, we recommend that you consult a professional .

StyleWell.™

Questions, problems, missing parts?
Before returning to the store, call Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.