


Item # 1001-090-652

Model # THD-ISCD

#### **USE AND CARE GUIDE**

#### **Imitation Security Camera**



THANK YOU

We appreciate the trust and confidence you have placed in Defiant through the purchase of we appreciate are data and continuely you need parter in the grant through and placinated or this limitation Security Camera. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Defiant you.

#### Warranty

#### 1 YEAR LIMITED WARRANTY

This product is guaranteed to be free of defects in materials and workmanship for 1 year from the date of purchase. If this product is defective, call 844-212-0200 for repair or replacement parts or return the product to the store from which it was purchased.

Guarantee does not include normal wear and tear, bulbs or batteries.

Contact the Customer Service Team or visit www.HOMEDEPOT.COM.

#### Safety Information

Save these instructions for future use.

WARNING: Any battery may leak harmful chemicals which may damage skin, clothing or the inside of the camera. TO AVOID RISK OF INJURY, DO NOT LET ANY MATERIAL LEAKED FROM A BATTERY COME IN CONTACT WITH EYES OR SKIN. Any battery may rupture or explode if put in a fire or otherwise exposed to excessive heat. TO AVOID RISK OF INJURY, DO NOT EXPOSE BATTERIES TO EXCESSIVE HEAT. To reduce the risk of personal injury or harm to your camera, take the following precautions:

- Do not use different brands of batteries in the same camera
- When replacing batteries always replace the whole set
- Do not use rechargeable or reusable batteries
- □ Do not allow children to install batteries unsupervised Follow battery manufacturer's instructions as to proper handling, storage and disposal of batteries

FOR INDOOR OR COVERED USE ONLY.

THIS PRODUCT CANNOT BE LINKED TO A MONITORED SECURITY

THIS PRODUCT IS NOT A REAL CAMERA. IT IS INTENDED TO DETER CRIME BY CREATING THE PERCEPTION OF A SECURITY CAMERA IN OPERATION. NOT RECOMMENDED FOR PUBLIC ENVIRONMENTS AND BUSINESSES. DEFIANT IS NOT RESPONSIBLE OR LIABLE FOR ANY DAMAGE, VANDALISM, THEFT OR OTHER ACTIONS THAT MAY OCCUR WHILE THIS PRODUCT IS IN USE.



WARNING: This product is not a toy. Keep children away. Do not allow them to handle the imitation camera.



WARNING: Do not dispose of this device with household waste. A selective collection system for this type of product is implemented by your local authorities. These restrictions apply because electrical and electronic devices contain dangerous substances that have harmful effects on the environment and human health and must be recycled.

#### PRODUCT DESCRIPTION

This realistic looking imitation camera is a simple and cost-effective solution to use as a visible deterrent to potential thieves. Along with the realistic design, this imitation camera also features a flashing red LED light which simulates the operation of an actual security camera.

#### PACKAGE CONTENTS

This imitation camera comes with 2 mounting screws and a mounting template and requires 3 AA batteries (not included) to operate the LED light.

# **DEFIANT®**

Questions, problems, missing parts? Before returning to the store, call Customer Service 8 a.m. - 4:30 p.m., CST, Monday - Friday

> 844-212-0200 HOMEDEPOT.COM

#### Installation

### 1 Installing the batteries

- □ Open the battery cover on the imitation camera.
- ☐ Insert 3 AA batteries (not included), ensuring the batteries match the + and - polarity markers in the battery housing.
- Place the battery cover back onto the imitation camera.

# 2 Mounting the imitation camera

- ☐ Use the mounting template provided to mark the locations of the
- Pre-drill holes in the mounting locations for the screws. If necessary. insert anchors into the mounting holes.
- □ Insert the screws into the mounting holes, ensuring that the screw heads are slightly separated from the mounting surface to allow for the mounting of the imitation camera.
- Position the imitation camera over the screw heads, matching the mounting holes on the back of the camera with the screw heads.
- $\square$  Twist to lock the camera in place on the screw heads.

#### Operation

# 3 Operating the dummy camera

- Once the batteries are properly installed, the red LED light will begin to flash, simulating an actual security camera.
- ☐ Check and replace the batteries every 2-3 months due to the continuous operation of the LED light.

