

FOR USE WITH GAS WATER HEATERS, FURNACES, SPACE HEATERS AND LOGS.

INSTALLATION INSTRUCTIONS

1. Shut off gas and remove old thermocouple from bracket and gas valve.
2. Install new thermocouple in pilot bracket.
3. Connect other end of the thermocouple to gas valve. Tighten on ¼ turn beyond finger tight.
4. Re-light pilot per appliance manufacturer's instructions.

If you have questions or need assistance, please call Rheem Sales Company tech support at 1-800-432-8373