

8-Pieces Outdoor Patio Furniture Set: Use & Care Manual

Introduction

Thank you for purchasing our 8-Pieces Outdoor Patio Wicker Sofa Set. This set includes combinable single sofas designed for garden conversations, featuring a durable gray wicker frame, supportive cushions, and a weather-resistant build. Follow this manual to ensure safe use, maintain longevity, and keep your furniture in optimal condition.

1. Safety Precautions

- **Assembly Safety:** Always wear gloves when assembling to avoid cuts from metal parts. Keep small tools (screws, wrenches) away from children and pets.
- **Stability:** Ensure the furniture is placed on a flat, level surface to prevent tipping. Do not use on uneven ground (e.g., slopes, gravel without a base).
- **Weight Limit:** Each single sofa has a maximum weight capacity of [specify if provided; if not, "check product label"]. Avoid standing or jumping on the furniture to prevent structural damage.
- **Extreme Weather:** Do not use during heavy rain, strong winds, or snowstorms. Move to shelter or cover immediately to avoid damage.

2. Assembly Instructions

1. **Unpack & Inspect:** Remove all parts from packaging. Check that all components (wicker frames, metal brackets, screws, cushions) are included and undamaged. Contact customer service if parts are missing or broken.
2. **Follow the Guide:** Use the included assembly diagram to connect frames. Tighten screws with the provided wrench—*do not over-tighten*(this may crack wicker or strip threads).
3. **Attach Cushions:** Place cushions on sofas once frames are fully assembled. Ensure cushions are centered to avoid slipping.

3. Usage Guidelines

- **Avoid Sharp Objects:** Do not place knives, tools, or sharp decor on wicker or cushions (may scratch wicker or tear fabric).
- **Limit Sun Exposure:** Prolonged direct sunlight may fade cushions. Use a patio umbrella

or move furniture to shaded areas when possible.

- **No Heavy Impact:** Do not drag furniture across rough surfaces (this may damage legs or wicker). Lift and carry when repositioning.

4. Care & Maintenance

A. Wicker Frame

- **Regular Cleaning:** Dust weekly with a soft-bristled brush or dry cloth to prevent dirt buildup.
- **Deep Cleaning:** For stains, wipe with a damp cloth and mild soapy water (e.g., dish soap diluted in water). Rinse with a clean, damp cloth and dry thoroughly with a towel to avoid moisture retention.
- **Avoid Harsh Chemicals:** Do not use bleach, abrasive cleaners, or pressure washers (may weaken or discolor wicker).

B. Metal Frame (Internal/Structural)

- **Rust Prevention:** The frame is pre-treated for rust resistance, but check joints monthly for signs of rust. Wipe away moisture promptly after rain.
- **Rust Treatment:** If minor rust appears, gently sand the area with fine-grit sandpaper, then apply a rust-resistant spray paint (match frame color if possible).

C. Cushions

- **Fabric Care:** Most cushions have removable, machine-washable covers (check care label for specifics).
 - *Machine Wash:* Use cold water, gentle cycle, and mild detergent. Air-dry completely (do not tumble dry, as heat may shrink or damage fabric).
 - *Non-Removable Covers:* Spot-clean stains with a damp cloth and mild soap. Blot (do not rub) to avoid spreading stains, then air-dry.
- **Water Resistance:** Cushions may be water-repellent but not fully waterproof. Remove cushions during rain and dry thoroughly before reuse to prevent mildew.