

Quick Start Guide


Cleaning can be overwhelming, so we kept things simple. In just a few easy steps, Bob will be ready to work!

Here's What You'll Need:

All parts are included in Bob's box.




Flat Head
Screwdriver




Side Brush




Side Brush Screw
(short screw)



Charging Station




Charging Adapter



Before starting, remove the clear plastic on Bob's power switch and flip Bob's power switch ON.


Step 1: Install the Side Brush

Secure the side brush into the socket on Bob's underside.




Step 2: Charge Bob

Place Bob on his charging station and allow him to charge. The metal plates on Bob's underside should sit on top of the nodes on his station.




Step 3: Let Bob Sweep!

Press the START button on Bob's cover.




Important Note:

Bob automatically returns to his charging station when low on battery. If Bob is having trouble finding his station, you will need to sync it. Refer to the Charging section of Bob's manual.



When Charging:

The battery bars and the word CHARGING flash.



When Fully Charged:

The word READY is lit.

Loving the Product?

Leave us a review! Rate us 5 stars and share your feedback on the site where you purchased Bob.

Not Impressed?

Let us help! Contact our support team at support@bobsweep.com or 1-888-549-8847. Our business hours are Monday – Friday, 9 a.m. – 5 p.m. Pacific Time.